

## ULTRA 2020 (330ml tank)



Ultrasonic cleaners function by producing sound waves that are transmitted into the tank and cleaning solution. These waves create millions of microscopic bubbles, which collapse or 'implode', releasing large amounts of energy, which scrub the surface clean. This process is called 'Cavitation'. These tiny bubbles create incredible cleaning results not only to the surface, but by penetrating the finer detail and recesses in jewellery and small items to restore them to their former glory. The ULTRA 2020 is so easy to use, just fill with warm water, add a little washing up liquid, place your jewellery in the water, close the lid, press the button and let the cleaner do the hard work for you.

The ULTRA 2020 is the perfect addition to every lady's powder room, with the choice of purple or blue lids and attractive wipe clean white plastic body, the ultrasonic cleaner will look good where ever you use it.

### Features:

- Automatic 3 minute timer
- 450ml stainless steel tank
- Sensory one touch ON/OFF button
- ON/OFF button works even when pressed without removing the lid
- Full CE and RoHS approval

### Specification:

Model name	ULTRA 2020
Tank Size	450ml (330ml max level)
Timer settings	Automatic - 3 minutes
Ultrasonic frequency	42,000Hz (42kHz)
Power consumption	30W Max
Power supply	AC 220-240V 50Hz
Unit dimensions (LWH)	196 x 118 x 119mm
Mains fuse	3A
Outer Unit LxWxH	196 x 118 x 119mm
Basket LxWxH	N/A
Weight	820 grams
Optimal fill	330ml
Maximum fill	330ml

Parto  
Shar