

ULTRA 7000S (750ml tank)



Ultrasonic cleaners function by producing sound waves that are transmitted into the tank and cleaning solution. These waves create millions of microscopic bubbles, which collapse or 'implode', releasing large amounts of energy, which scrub the surface clean. This process is called 'Cavitation'. These tiny bubbles create incredible cleaning results not only to the surface, but by penetrating the finer detail and recesses in jewellery and small items to restore them to their former glory.

The control panel of the Ultra 7000S cleaner has a simple to use Digital Timer. Set your required cleaning time to one of the five pre-set times between 90 seconds and 10 minutes and let the cleaner do the hard work for you.

Despite the compact size, the Ultra 7000S has a large 750ml tank. The basket will carry many small items, saving time and keeping them secure. CD/DVD's can also be cleaned using the holder. Another useful addition is the Watch/Earring stand that allows your valuables to be securely placed while cleaning.

Features:

- Digital timer with 5 time settings with auto shut-off
- Large 700ml stainless steel tank
- Fast, efficient effortless cleaning
- Suitable for home and professional use
- Cleans CDs/DVDs - holder included
- Ultrasonic operating frequency 42KHz
- Watch/earring stand included
- Supplied ready to use - no assembly required
- Full CE and RoHS approval

Specification:

Model name	ULTRA 7000S
Tank volume	750ml
Timer settings	Digital operation with 5 cycles: 90, 180, 300, 480 and 600 seconds with auto-shut-off
Tank material	Stainless steel SUS304
Ultrasonic frequency	42,000Hz (42kHz)
Power consumption	50W Max
Power supply	AC 220-240V 50Hz
Unit dimensions (LWH)	230 x 171 x 142mm
Tank LxWxH	150 x 125 x 45mm
Outer Unit LxWxH	230 x 171 x 142mm
Basket LxWxH	143 x 121 x 42mm
Weight	1100 grams
Optimal fill	549ml
Maximum fill	750ml