

ULTRA 7000 (750ml tank)



Ultrasonic cleaners function by producing sound waves that are transmitted into the tank and cleaning solution. These waves create millions of microscopic bubbles, which collapse or 'implode', releasing large amounts of energy, which scrub the surface clean. This process is called 'Cavitation'. These tiny bubbles create incredible cleaning results not only to the surface, but by penetrating the finer detail and recesses in jewellery and small items to restore them to their former glory. The control panel of the Ultra 7000 cleaner has a simple to use Digital Timer. Set your required cleaning time to one of the five pre-set times between 90 seconds and 8 minutes and let the cleaner do the hard work for you. Despite the compact size, the Ultra 7000 has a large 750ml tank. The basket will carry many small items, saving time and keeping them secure. CD/DVD's can also be cleaned using the holder. Another useful addition is the Watch/Earring stand that allows your valuables to be securely placed while cleaning.

Features:

- Fast, efficient, effortless cleaning
- Ultra-quiet operation
- Green cleaning - uses warm tap water
- Innovative patented design
- High quality stainless steel tank
- Ultrasonic operating frequency 42KHz
- Mains power NOT battery for quality cleaning results
- Supplied ready to use - no assembly required
- Full CE and RoHS approval

Specification:

Model name	ULTRA 7000
Tank volume	750ml max
Timer settings	Digital timer with 5 time settings: 90s - 480s (8min) with automatic shut-off
Tank material	Stainless steel SUS304
Ultrasonic frequency	42,000Hz (42kHz)
Power consumption	50W Max
Power supply	AC 220-240V 50Hz
Unit dimensions (LWH)	210 x 158 x 125mm max
Net weight	1kg (2.2lbs)
Mains fuse	3A
Tank LxWxH	149 x 126 x 47mm
Outer Unit LxWxH	210 x 158 x 125mm
Basket LxWxH	143 x 121 x 42mm
Weight	1000 grams
Optimal fill	526ml
Maximum fill	750ml